

BONDING A COMBINATION WORK

The working procedure and the precision for bonding the abutment retainers are extremely important. They guarantee the parallelism and a longer life of the combination work.

1. Check if the construction parts fit accurately in the mouth.
2. Lubricate the space maintainers with vaseline and place them on the spring pins.
3. Bond the abutment retainers.
4. Immediately press the removable prosthesis over the abutment retainers and bring the patient's jaws manually in centric relation.
5. Allow the composite to set.
6. Remove the secondary construction and the composite residues from the primary and secondary parts.
7. Check the snap and the retention of the attachments (see INFO 059).

Side effects, warnings and precautions

- The attachments are intended for single use.
- The products are non-sterile.
- There is a risk of poor fit when patient conditions change.
- Bacterial adhesion can be avoided by applying hygiene measures.
- Inappropriate use or bad manufacturing can lead to premature wear of the attachments.
- The functionality of the attachments will be adversely affected by traumas such as grinding and bruxism.
- For the purpose of traceability we advise you to record the lot number of the applied products in the patient file.
- Do not heat items containing titanium.
- Do not use items containing nickel in case of nickel allergy.
- The accessories RE H 79 and H 35 must be used outside the mouth.