

PROCESSING PRECI-CLIX RADICULAR

CHAIRSIDE PROCEDURE

1. Determine the path of insertion of the prosthesis and try to parallel the root accesses.
2. Prepare the root canals according to the situation.
3. Use the **1227** predrilling burr to prepare the root.
4. The **1228** cavity burr will prepare the seating of the cementable post base.
5. Use the **1229** precision reamer to calibrate the diameter for the **1291 C** post.
6. Screw the **RE H 2** impression tool into the **1291 C** post to facilitate cementation.
7. Clean, degrease, and cement the post into the root.
8. Remove all excess cement.
9. Do the final polishing of the root.
10. Take a full arch impression with the impression tool still in position.

LABORATORY PROCEDURE

1. Parallel the females with the **1211 P** paralleling mandrel.
2. Assemble the **RE H 2** impression tool with the **RE H 14** model analogue and pour a working model.
3. Remove the impression tool and replace it with a **1206 C** PRECI-BALL male using the **IMP-XS-042** screw-driver.
4. Fill up the space between papilla and root with plaster.
5. Press with the **1222** insertion tool a **1231** PRECI-CLIX female into the **1235** TITANAX housing.
6. Place the **1251 B** rubber space maintainer over the male and assemble with the female and the housing.
7. Place the **RA 0055** large space maintainer over the male on the post-coping. Adjust it until it covers the edge of the papilla by 1 to 1.5 mm.
8. Apply a small amount of vaseline to the inside of the female. Keep the retention zone for acrylic resin and the outside of the housing clean.
9. Position the wax setup on the model. Prepare for investing.
10. Polymerize and finish.
11. Remove the space maintainers after polymerization.
12. Check the retention and replace the female if necessary by a **1232** white female with reduced retention or a **1233** red female with increased retention.